

Pure Freude
an Wasser



42 789 000 HOUSING ELECTRONIC FOR 37 751

PRODUCT DESCRIPTION

- Colour: chrome



Pure Freude
an Wasser



42 789 000 HOUSING ELECTRONIC FOR 37 751

No exploded view is available for this spare part list.

SPARE PARTS, January 1999 – now

1: Fastening screw for 37751 (Spare part-nr. 42788000)

2: Battery (Spare part-nr. 42886000)